## RB720DH

# Hotpoint® 30" Free-Standing Electric Range

### Dimensions and Installation Information (in inches)

#### **Receptacle Locations**


Locally approved flexible service cord or conduit must be used because terminals are not accessible after range installation. See shaded area in drawing for location of electrical outlet box. Recommended outlet locations allow range to be installed directly against wall.

**Note:** This appliance has been approved for 0" spacing to adjacent surfaces above the cooktop. However, a 6" minimum spacing to surfaces less than 15" above the cooktop and adjacent cabinet is recommended to reduce exposure to steam, grease splatter and heat.

**Installation Information:** Before installing, consult installation instructions for current dimensional data and additional requirements.

| KW Rating    |                      |
|--------------|----------------------|
| 240V         | 11.7                 |
| 208V         | 8.8                  |
| Breaker Size |                      |
| 240V         | 40 Amps†             |
| 208V         | 40 Amps <sup>†</sup> |

<sup>†</sup>**Note:** Check local codes for required breaker size.





For answers to your Monogram® or GE® appliance questions, visit our website at geappliances.com or call GE Answer Center® service, 800.626.2000.



**26-1/4** w/o handle

All GE ranges are equipped with an Anti-Tip device. The installation of this device is an important, required step in the installation of the range.

46-3/4

36-1/2

### RB720DH

## Hotpoint® 30" Free-Standing Electric Range

#### Features and Benefits

- Self-Clean Oven Cleans the oven cavity without the need for scrubbing
- 5.0 cu. ft. Oven Capacity Cook more dishes at once
- Coil heating elements Provides consistent and even heat on the cooktop with a plug-in element that is removable for easy cleaning
- Electronic Oven Controls Electronic touch pads are easy to operate
- Big View Window Provides a large, convenient viewing area to check the progress of food
- Frameless Glass Oven Door Simple, stylish and easy to clean
- Porcelain Upswept Cooktop Raised edges contain spills, while the surface is easy to wipe clean
- Two Oven Racks Durable to securely hold any cookware
- Interior Oven Light Illuminates the oven interior
- Audible Preheat Signal Know when the oven is ready
- Removable Full-Width Storage Drawer Store cookware or kitchen accessories
- Model RB720DHBB Black on black
- Model RB720DHWW White on white
- Model RB720DHCC Bisque on bisque

